


Tube No.
177UR

WATER VAPOUR




1. PERFORMANCE

- 1) Measuring range : 2-12 LB/MMCF
Number of pump strokes : 2 (200mℓ)
- 2) Sampling time : 2 minutes/2 pump strokes
- 3) Detectable limit : 1 LB/MMCF
- 4) Shelf life : 3 years
- 5) Operating temperature : 0 ~ 35 °C
- 6) Temperature compensation : Necessary (See "TEMPERATURE CORRECTION TABLE")
- 7) Reading : Direct reading from the scale calibrated by 2 pump strokes
- 8) Colour change : Yellow → Yellowish green

2. RELATIVE STANDARD DEVIATION

RSD-low : 10 % RSD-mid. : 10 % RSD-high : 10 %

3. CHEMICAL REACTION



4. CALIBRATION OF THE TUBE

DIFFUSION TUBE METHOD

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	Coexistence
Alcohols	Similar stain is produced.	Higher readings are given.
Benzene	The accuracy of readings is not affected.	
Toluene	∕	
Hexane	∕	
Sulphur oxide	∕	
Hydrogen sulphide	∕	

TEMPERATURE CORRECTION TABLE

Temperature : To correct for temperature, multiply the tube reading by the following factors.

Temperature (°C)	0	1	2	3	4	5	6	7	8	9
Correction Factor	1.69	1.65	1.61	1.57	1.53	1.50	1.46	1.42	1.39	1.35
Temperature (°C)	10	11	12	13	14	15	16	17	18	19
Correction Factor	1.32	1.28	1.25	1.22	1.19	1.15	1.12	1.09	1.06	1.03
Temperature (°C)	20	21	22	23	24	25	26	27	28	29
Correction Factor	1.00	0.98	0.95	0.92	0.90	0.87	0.85	0.82	0.80	0.78
Temperature (°C)	30	31	32	33	34	35				
Correction Factor	0.75	0.73	0.71	0.69	0.67	0.65				