

# Gilian®



## **GilAir® PLUS**

### Tri-Pod Mounting Instructions

***SENSIDYNE®***  
*Industrial Health & Safety Instrumentation*

1000 112<sup>TH</sup> Circle N, Suite 100 • St. Petersburg, FL 33716 USA

(800) 451-9444 • +1 (727) 530-3602  
www.Sensidyne.com • info@Sensidyne.com





REF 360-0198-01rB

## Equipment Required:

---

	Tri-Pod Mount
	Any Tri-Pod with Standard Mounting Plate
	6” – 8” Standard Cable Tie
	GilAir Plus Air Sampling Pump

**Instructions**

1		<p>Attach Tri-Pod Bracket to Tri-Pod Mounting Plate Screw as shown.</p>
2		<p>Attach GilAir Plus Air Sampling Pump by sliding Belt Clip over Tri-Pod Bracket until Pump seats on bottom of Bracket as shown.</p>
3		<p>Secure GilAir Plus Air Sampling Pump to Tri-Pod Bracket by feeding a 6" to 8" Cable Tie through each side of the Bracket passing through the Belt Clip.</p>
4		<p>The GilAir Plus Air Sampling Pump is now secured to the Tri-Pod and ready for sampling.</p>

**Manufactured by:**

**Sensidyne, LP**

1000 112<sup>th</sup> Circle N, Suite 100  
St. Petersburg, Florida 33716  
U.S.A.

800-451-9444 • +1 727-530-3602 • [fax] +1 727-539-0550  
www.Sensidyne.com • info@Sensidyne.com

**Authorized EU Representative**

**Schauenburg Electronic Technologies GmbH**

Weseler Str. 35 · 45478  
Mülheim-Ruhr Germany

+49 (0) 208 9 99 10 • +49 (0) 208 5 41 10 [fax]  
www.schauenburg.com • international@schauenburg.com

***SENSIDYNE***<sup>®</sup>  
*Industrial Health & Safety Instrumentation*

1000 112<sup>th</sup> Circle N, Suite 100 • St. Petersburg, FL 33716 USA  
(800) 451-9444 • +1 (727) 530-3602  
www.Sensidyne.com • info@Sensidyne.com