


ETHYL MERCAPTAN



1. PERFORMANCE


- 1) Measuring range : 5-80 ppm 2.5-40 ppm
Number of pump strokes: 1/2(50mL) 1(100mL)
- 2) Sampling time : 30 seconds/ 1/2 pump strokes
- 3) Detectable limit : 1 ppm(100mL)
- 4) Shelf life : 2 years
- 5) Operating temperature : 0~40°C
- 6) Reading : Direct reading from the scale calibrated by 1/2 pump strokes
- 7) Colour change : Yellow→Pink

2. RELATIVE STANDARD DEVIATION

RSD-low : 15% RSD-mid. : 10% RSD-high : 5%

3. CHEMICAL REACTION

By reacting with Mercuric chloride, Hydrogen chloride is produced and PH indicator is discoloured.



4. CALIBRATION OF THE TUBE

STANDARD GAS CYLINDER METHOD

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	ppm	Coexistence
Hydrogen sulphide	Similar stain is produced.		Higher readings are given.
Phosphine	"		"
Other mercaptans	"		"
Arsine	"		"
Hydrogen selenide	"		"
Hydrogen cyanide	"		"
Nitrogen dioxide	The accuracy of readings is not affected.		Lower readings are given.
Ammonia	"		"
Sulphur dioxide	"		"

(NOTE)

In case of a 1 pump stroke, following formula is available for the actual concentration
Actual concentration = 0.5 x Reading value